Alcatel Premium Reflexes™

Alcatel OmniPCX Office







ALCATEL

ARCHITECTS OF AN INTERNET WORLD

How to use this guide?

You have an Alcatel Premium Reflexes digital telephone. The alphabetic keypad, the screen and the icons will help you use your telephone easily and make optimum use of the many functions offered.

Actions





Lift receiver.



Loudspeaker.



Hang up.



Hands free.



Description of an action or context.



Adjustment "reduce".





Adjustment "increase".



Partial view of display.

• Programmable keys and icons Line key.



Fixed key.

Other fixed keys



Icon corresponding to





key.



MENU key.



Key programmed by technician to access service.









Alternative to action sequence.



Alphabetic keypad.





Important informations.




Specific key on numeric keypad.

These symbols can be supplemented by small icons or text. All default or customized function codes are given in the table of codes in the appended sheet.

Contents

	Getting to know your telephone p.4
1.	Getting started p.6 Identify the terminal you are on. Making and receiving a call. Initializing your voice mailbox. Consulting your voice mailbox. Adjusting your telephone settings: ringer and brightness. Programming direct call keys. Installing the programmable key label.
2.	Using your telephone
3.	During your communication p.11 Sending DTMF signals. Calling a second person during a conversation. Receiving a second call. Switching between two calls (Broker call). Transferring a call. Three-way conference.
4.	Your telephone fits your needs p.13 Programming your personal directory. Customising your voice greeting. Personal assistant: reaching you with one number only. Modifying your personal code.
5.	Keep in touch
6.	Sharing
	Guarantee and clauses p.19

Getting to know your telephone



Display

The screen displays several pages of information concerning the present call.

Programmable keys and icons

To make a call, activate a service or manage your calls. Icons are associated with each of these keys:

Line icons:

Incoming call (flashing).

Call in progress.

Call on hold.

Call on common hold.

Function icons:

Function active.

Function requiring action.

Terminal or line busy.

Preprogrammed function keys:

Display new page.

() Divert your calls to another terminal.

(** Three-way conference.

Automatically redial the last number dialled.

Access the various mail services.

Transfer call to another terminal.

Getting started

1.1

Identify the terminal you are on

Press this key twice.

1.2

Making and receiving a call

• To make a call:











lift the receiver

hands free

for an outside line

dial the number for your call

• To answer:







lift the receiver

hands free

1.3

Initializing your voice mailbox

Light flashes



enter your personal code then record your name according to voice guide instructions



Your personal code is used to access your voice mailbox and to lock your telephone.

1.4 Consulting your voice mailbox









display of sender's identity and message broadcasting

personal code









select message

replay message

1.5 Adjusting your telephone settings : ringer and brightness













ringer

brightness

for the ringer, press repeatedly on











choose ringer

choose volume

apply

for brightness, press repeatedly on









apply

1.6 Programming direct call keys













press programmed key

present value of selected key

enter the





apply

1.7 Installing the programmable key label

A printed label is supplied with the terminal. This should be installed beneath the programmable keys.



- I. Insert a flat "blade" into the slot (I slot per key block).
- 2. Raise the cover.
- 3. Slide the printed label into position.
- 4. Replace the cover.

2 Using your telephone

2.1 Making a call











key





lift the receiver

hands free

programmed line

OR

dial the number for your call



For an outside line, dial '9' before the number. For the operator, dial '0'.

2.2 Receiving a call







lift the receiver hands free

2.3 Callin

Calling your correspondent by his name





display the correspondent's identity



enter the first letters of the name

2.4 Calling from your personal directory





directory

directory number required (0 to 9)



To program your personal directory, refer to the paragraph 'Programming your personal directory'.

2.5 Redialling





0155667000

redial

number called

2.6

Requesting automatic callback if internal number is busy

internal number busy









"Automatic callback if terminal busy" programmed key or function code

During your communication

During a conversation, different operations like calling a second person or transferring a call to another number can be done.

3.1

Sending DTMF signals

During a conversation you sometimes have to send DTMF signals, such as with a voice server, a PABX or a remotely consulted answering machine The function is automatically cancelled when you hang up.

during a conversation









cancel

"DTMF End to End" programmed key or function code

3.2

Calling a second person during a conversation

During a conversation, to call a second person.











the first call is on hold

dial number required

enter the first letters of the name

line key

3.3 Receiving a second call

During a conversation, another person is trying to call you.

Smith John



the first call is on hold

caller's name or number flashing for 3 seconds

press line key with icon flashing

3.4

Switching between two calls (Broker call)

During a conversation, another call is on hold. To accept the second call:





the first call is on hold

press line key with icon flashing

3.5

Transferring a call

During a conversation, to transfer the call to another number.







Number to be called

transfer

3.6

Three-way conference

During a conversation, a second call is on hold.







3-way conference

cancel conference and return to first correspondent

hang up on all correspondents

4

Your telephone fits your needs

4.1 Programming your personal directory











directory number (0 to 9)

present value displayed









enter correspondent's number

erase present value











erase present value

internal or outside number to be entered

4.2 Customising your voice greeting

You can replace the greeting message by a personal message.













voice message service















end of recording

apply

to return to the default message

4.3 Personal assistant : reaching you with one number only











personal assistant select type of diversion

dial number of a colleague or your













dial an outside line number

dial number of your mobile or DECT

activate/ deactivate transfer to operator

4.4 Modifying your personal code

Your personal code is used to access your voice mailbox and to lock your telephone. As long as your voice mailbox has not been initialized, personal code is 1515.











options

personal code

old code (4 digits).







apply

5 Keep in touch


If you do nothing, Alcatel OmniPCX Office diverts calls to your voice mailbox.

5.1 Diverting your calls to your voice message service



5.2 When you return, consult recorded messages

The light indicates that messages have been received.



5.3 Diverting your calls to another number







divert

destination number

5.4 When you return, cancel all diversions





programme another type of diversion

Activate/disable the personal assistant









personal assistant display status

personal assistant











to activate personal assistant

to deactivate personal assistant

apply

Sharing

Call pick-up









'Terminal call pick-up' programmed key or function code

number of

6.2 Answering a general bell

telephone ringing

If the operator is absent, to answer incoming calls to the operator.

General bell is ringing



'General bell' programmed key

6.3 Filtering manager/secretary





incoming calls are filtered by a chosen person (secretary, etc.)



"Filter" programmed key same key to cancel

6.4

Send a voice message copy





display number of new and old messages















personal code

select message to copy

copy message









Number to be called

correspond ent's name

apply











add a correspondent

record a comment

send message

Guarantee and clauses

Independently of the legal warranty that covers this appliance, it is guaranteed for I year, parts and labour, counting from the date indicated on your invoice. Nevertheless, if the legal warranty in effect in your country exceeds I year, then the legal warranty is the sole warranty applicable.

The invoice will be demanded if making a claim under the warranty. The warranty does not however apply in the following cases: in the event of use that does not comply with the instructions given in this user's manual, faults or damage caused by natural wear, damage resulting from a cause external to the appliance (e.g. impact, fall, exposure to dampness, etc.), noncompliant installation or modifications or repairs carried out by people who are not approved by the manufacturer or retailer.

Declaration of compliance

We, Alcatel Business Systems, hereby declare that we assume the Alcatel Premium Reflexes to be compliant with the essential requirements of Directive 1999/5/CE of the European Parliament and Council.

Any unauthorised modification to the product shall render this declaration of compliance null and void. A copy of the original of this declaration of compliance can be obtained by post from:

Alcatel Business Systems - Technical Services - Customer Care I, route du Dr. Albert Schweitzer - F 67408 Illkirch Cedex - France

The CE marking indicates that this product complies with the following EC directives:

(F:

89/336/CEE (electromagnetic compatibility)

73/23/CEE (low voltage)
 1999/5/CE (R&TTE)

Some of your telephone's functions require a software key or are only accessible once programmed by your installation technician.

For further information, visit our web site www.alcatel.com

Copyright © ALCATEL. 2000. All rights reserved.

Alcatel Business Systems, in keeping with its policy of constant product improvement for the customer, reserves the right to modify product specifications without prior notice.

ALCATEL - 32, avenue Kléber, F-92707 Colombes Cedex

R.C. Paris 602 033 185

3EH 21002 BSAA Ed.01