

Resetting and re-registering Engenius Phone.

If the phone stops working try these steps.

1. Disconnect power from base station for 30 seconds and reconnect.
(un-plug round DC IN power connector see image below) Test handset again.
If now working no further action is required. If not working go to step 2.



2. If still not working Press and hold the grey REG button until all LEDs on the front of the base station are lit.

Once all LEDs on the Base Station are lit quickly select Menu 6 1 to re-register the handset. If you're too slow the Base will exit registration mode, if so simply press and hold the grey REG button again until all LEDs are lit.

The Menu button is the far right hand white semi circle button.

Phone will display "Searching for Base" as per the photos, once registered the handset will briefly display "Registration Complete".

